

Three wheel bicycle – tricycle

„Sparite” instruction manual

Dear customers!

This bicycle provides stability and feeling safe especially on uneven surfaces, because it does not create sharp toppling and overturn risks unlike two wheel bicycles with additional wheels. A child quickly learns to ride a traditional bicycle, because this bicycle has a chain drive mechanism instead of traditional front wheel drive.

Carefully read and remember

Never leave child on three wheel bicycle without supervision.

Do not let the child ride on car drive lanes, close to water drains, stairs and other places dangerous to safety of children.

Carefully follow in hilly landscapes, because when riding from hill there is a possibility of speed increase not suitable for your child.

Safety requirements

Before putting a child on three wheel bicycle carefully read instruction manual!

Non-compliance with requirements of instructions can affect your safety and technical condition of the three wheel bicycle.

Your three wheel bicycle meets factory standards and is not designed for purposes which are not related to riding.

Check the front wheel axle nuts before operation. The torque must be tight.

Do not allow child to touch wheel mechanism, pedal mechanism, chain and other mechanically moving parts when three wheel bicycle is moving.

Handlebar and saddle tubes can be tightened by a clamp which is located on its base part. Carefully but tightly tighten the clamp in necessary height. Do not over-tighten the clamp.

Check if saddle and handlebar extension height is adjusted properly, they must not be higher than specified mark!

Saddle and handlebar extension height is adjusted properly if sitting on three wheel bicycle both legs are completely straight and the ground can be touched only by tips of the toes.

Chain tensioning

1. Unscrew and take off frontal part of chain guard.
2. Loosen (but do not remove completely) bolt, nut of the clamp of the pedal mechanism.
3. Put a circle spanner wrench or pliers on pedal mechanism – eccentric bushing (together with metal casing) where is a notch and turn eccentric bushing as necessary. When the centre of pedal axle moves away from rear axle of three wheel bicycle the chain tension increases but when it comes closer to rear axle the chain tension decreases.
4. Tighten pedal mechanism bolt and nut.
5. Tighten the rear part of chain guard; if necessary (unscrew chain guard fastening bolts).
6. Verify that the chain is tensioned enough and does not rub.
7. Put on the chain guard frontal part and fasten with a screw.

Three wheel bicycle maintenance

Regularly wipe off dirt from three wheel bicycle. Use cleaning agents when washing three wheel bicycle with water.

Timely lubricate bushings and chain.

Do not use lubricants from vegetable raw materials as it can create a harmful patina.

If necessary, three wheel bicycle maintenance can be done by manufacturer or other specialist.

Guarantee liabilities

The guarantee comes in force on the day of purchase.

Guarantee duration is 1 (one) year.

During guarantee, parts exchange and elimination of other defects are free of charge, if they have originated due to damaged parts or incorrect industrial assemblage.

The guarantee is void if damage originated because of incorrect use of three wheel bicycle i.e. if maintenance and usage conditions not met, if incorrect lubricants are used, if it has been used when incorrectly adjusted (insufficient insertion of saddle or handlebar tubes into carriage) or incorrectly mated, or the riding on road edges or other obstacles have been done. The guarantee is void in case of natural wearing of parts (e.g. for chains, tyres, chain rings, bushings), if the three wheel bicycle has been overloaded, if there has been an accident, if it has been misused or if the three wheel bicycle has been used for other purposes (amateur three wheel bicycle used in extreme traces or in competitions).

Guarantee repairs are made when customer presents purchase receipt and three wheel bicycle passport received when purchased.

For guarantee service contact:

SIA “Velo machine”

Helmaņa iela 11, Sigulda

e-mail: velomachine@inbox.lv

Guarantee sheet

Three wheel bicycle model:

Date of sale:

Name, surname of buyer,
signature:

Signature of sales clerk:

Guarantee repairs are made within 10 (ten) days.